

CK SERIES BURIED SERVICE WIRE KITS

A Quick Method For Splicing Buried Service Wire

- **Fast Installation**
- **Moisture Proof**
- **Fully Self-Contained**
- **Fungus Resistant**
- **Non Re-enterable**



BENEFITS

Economical

The Buried Service Wire Kit saves time and money with every installation. *The cost of recalls on drop wire splice failure is eliminated.*

Safe

The encapsulant material is self-contained in a heavy-duty mixing tube. An exterior safety bag encloses the tube virtually erasing any exposure to field technician.

Dependability

Uraseal Buried Service Wire Kits provide positive moisture proof protection for drop wire cables. This proven technology has been used by major operating companies for over 3 decades without failure.

Self-Contained

Everything needed to encapsulate your spliced wire is included in the kit.

Versatile

The CK-BSV is universal for any type of splice configuration. *It is particularly suited to applications where there is not a lot of room to maneuver, or where there is limited slack available.*

DESCRIPTION

Uraseal, Inc. Buried Service Wire Splice Kits are designed to quickly and permanently encapsulate buried drop wire cables. The CK kit has **passed** a severe 100 cycle, thermo-cycling and moisture penetration test.

Buried Service Drop Wire Kits

Product Selection

Product Number	Compound Needed (gm)	Drop Wire Size (pr)	Units / Carton	Approx. Shipping Weight (lbs.)
CK137	95	2-3	50	18
CK137B	95	2-3	50	18
CK137BS	95	2-3	50	18
CK200	145	2-6	50	24
CK200B	145	2-6	50	24
CK200BS	145	2-6	50	24
CK200BSV	159	2-6	30	23

All CK Buried Service Wire Kits are individually packaged in moisture-proof bags. The individual kits are then “bulk packed” in shipping cartons.

Installation

(Traditional Butt Splice)

- Prepare the wire splice
- Mix Encapsulant
- Insert Splice Into Encapsulant

(In-Line Or Vertical Splices BSV kits)

- Install Closure
- Mix and Pour Encapsulant

** Complete Installation instructions are provided with each splice kit and are available upon request.*

Note: “B: kits include bonding bolt. “BS” kits include the bonding bolt and the foam stopper for immediate burial. “BSV” kits include bonding hardware, two foam stoppers and a clamshell-like closure.